





BACK STYLE: Bustle inside back with motorized adjustable headrest

DESIGN NOTE: Activator switches on motorized recliners feature a USB port.

	DIME	INSIONS:	Width	Depth	Height	Inside Width	Seat Height	Seat Depth	Arm Height	Overall Length Fully Reclined	Wall Clearance Needed	Footrest Extension
	734-83	Motorized Reclining Chair with Headrest	30	42	40	21	22	18	26	71	4	20
	734-87	Motorized Swivel Glider Reclining Chair with Headrest (shown)	30	42	40	21	22	18	26	67	11	18
	734-90	Motorized Glider Reclining Chair with Headrest	30	42	40	21	22	18	26	67	11	18

Battery Pack Available









BACK STYLE: Bustle inside back with motorized adjustable headrest

DESIGN NOTE: Activator switches on motorized recliners feature a USB port.

	DIMENSIONS:		Width	Depth	Height	Inside Width	Seat Height	Seat Depth	Arm Height	Overall Length Fully Reclined	Wall Clearance Needed	Footrest Extension
	734-83	Motorized Reclining Chair with Headrest	30	42	40	21	22	18	26	71	4	20
>	734-87	Motorized Swivel Glider Reclining Chair with Headrest (shown)	30	42	40	21	22	18	26	67	11	18
	734-90	Motorized Glider Reclining Chair with Headrest	30	42	40	21	22	18	26	67	11	18

Battery Pack Available

