




## **FEATURES:**

BACK STYLE: Bustle inside back

**DESIGN NOTE:** Activator switches for motorized recliners feature a

USB and charging port for the mounted battery.



<sup>\*</sup> Mounted Battery Pack







## **FEATURES:**

BACK STYLE: Bustle inside back

Activator switches for motorized recliners feature a USB and charging port for the mounted battery. **DESIGN NOTE:** 

DIMENSIONS:		Width	Depth	Height	Inside Width	Seat Height	Seat Depth	Arm Height	Overall Length Fully Reclined	Wall Clearance Needed	Footrest Extension
781-37	Reclining Chair	37	41	44	22	21	19	26	73	5	20
781-38*	Motorized Reclining Chair	37	41	44	22	21	19	26	71	5	20
781-59	Swivel Glider Reclining Chair	37	41	44	22	21	19	26	71	13	20
781-78*	Motorized Swivel Glider Reclining Chair (shown)	37	41	44	22	21	19	26	68	13	18

<sup>\*</sup> Mounted Battery Pack

