


The following information relates to the functionality, mounting of battery packs, and charging ports used on Smith Brothers of Berne Inc. furniture. Battery life between charges will vary depending on use of chair and devices being charged off chair battery only.

Charging Instructions:

1. Connect the female plug of the transformer to the male plug of the battery. Then connect the charger to the main electrical supply outlet.

Battery —————→

Transformer —————→



2. The red light on the battery will flash while the battery is charging. (It may take several seconds after connecting to power source.)

Once the battery has consumed its useful life the recliner motor will not be operational until the battery pack is replaced with another or replaced with the transformer to be ran directly from the electrical outlet.



3. When the light changes to green, charging is complete. Disconnect the power supply unit from the main electrical source and then disconnect the transformer from the charger.

Leaving a fully charged battery connected to the main power source for an extended period of time may damage the battery.



4. Reconnect the battery to the recliner chair (if the cable had previously been disconnected.)

Charging Port and Battery Mounting on Select Styles:

On select styles, a charging port is located on the exterior of the upholstered furniture. It may be located alone towards the back of the recliner (Fig. 1) or located in the switch assembly (Fig. 2).

In these instances, the battery is mounted under the chair. Assistance may be needed to lay the chair down to diagnose any issues with the battery (Fig. 3).

CAUTION: Do not engage the mechanism while the chair is laying down. This can cause binding issues with the mech and make it inoperable.



Fig. 1



Fig. 2




Fig. 3




Fig. 3

View from under recliner